# TOYOTA COASTER



**MOVE MORE** 





Engine and Drivetrain			
Bore x Stroke (mm)	92.0 x 103.6	104.0 x 118.0	
Fuel Filter	•	•	
Fuel Heater	•		
Fuel System	Diesel Common Rail	Diesel Common Rail	
Maximum Power (kW @ r/min)	110 @ 2500	100 @ 3000	
Maximum Torque (Nm @ r/min)	420 @ 1400	353 @ 1600	
Number of Cylinders and Arrangement	Inline-4	Inline-4	
Sequential shift	•		
Transmission Oil Cooler	•		
Engine capacity (litre)	2.8	4.0	
Transmission			
Transmission	Automatic-6-speed	Manual-5-speed	
Driven Wheels	RWD	RWD	
Starting System	Rotary (Mechanical)	Rotary (Mechanical)	
Suspension			
Front	Double Wishbone	Double Wishbone	
Rear	Leaf-Spring	Leaf-Spring	
Wheels and Tyres			
Spare Wheel	Full Steel	Full Steel	
Tyre Size	F:215-70R17.5 Steel R:215-70R17.5 Steel	F:215-70R17.5 Steel R:215-70R17.5 Steel	
Body and Styling			
Door Outside Handles	Black	Black	
Front Bumper	Colour Coded	Colour Coded	
Front Fog Lamps	•		
Windshield Glass	Laminated, Green	Laminated, Green	
Headlights	LED	Halogen	
Headlamp Levelling	Standard Manual	Standard Manual	
High-Mounted Brake Light	•	•	
Light Control System	Autocut		
Side Mirrors	Black	Black	
Front Grille	Black	Black	
Rear Bumper	Colour Coded	Colour Coded	
Rear Fog Lamp	•		
Front side Glass	Grey	Green	
Rear side Glass	Grey	Green	



Body and Styling	
Back Glass	Green Green
Front Spoiler	•
Side Step	•
Interior, Comfort and Convenience	
AT Shift Lock	•
Clock	•
Cupholders	•
Floor Carpet Trim	PVC PVC
Front Headrest	Adjustable 1 Adjustable 1
Key Reminder Warning	
Meter Illumination Control	•
Room Lamp	•
Seat Trim	Fabric PVC
Shift Lever & Knob	Urethane Urethane
Speedometer	Analog Tachometer Analog Tachometer
Steering Wheel	2 Spoke Urethane 2 Spoke Urethane
Airconditioner	Manual Manual
Audio System	Toyota Display Audio, RDS Toyota RDS
Reverse Camera	Display Audio
Bluetooth	•
Disc type	Standard CD
Footrest	•
Front Seat Reclining	Driver Manual Driver Manual
Heater	Manual Manual
Multi-Information Display	•
Power Socket	Front - 12V Front - 12V
Power Steering	Hydraulic Hydraulic
Speakers	Standard 4 Standard 4
Steering Column Adjustments	Manual Tilt & Telescopic Manual Tilt & Telescopic
Sun Visor	Standard Ticket Holder Driver Standard Ticket Holder Driver
USB	•
Door Courtesy Lamp	•




Toyota Connect Enabled	•	•	
Auxiliary Input		•	
Safety and Security			
Anti-Theft System	Immobiliser Alarm	Immobiliser Alarm	
Parking Brake	Lever	Lever	
Front Brake	Ventilated Disc	Ventilated Disc	
Front Seat Belts	ELR, Pretensioner, Force Limiter	ELR, Pretensioner, Force Limiter	
Over-Run and Speed Limiter	Standard 100	Standard 100	
Power Door Lock	Standard	Standard	
Rear Brake	Drum	Drum	
Rear Seat Belts	Standard ELR	Standard ELR	
Brake Warning	•	•	
Airbags	Driver, Passenger	Driver, Passenger	
Driver Support Systems			
Anti-Lock Braking System (ABS)	•	•	
Brake Assist (BA)	•	•	
Electronic Brake Force Distribution (EBD)	•	•	
Hill Assist Control (HAC)	•	•	
Vehicle Stability Control (VSC)			
tames and the control (196)	•	•	
Service and Warranty	•	•	
	6 Services / 60,000km	6 Services / 60,000km	
Service and Warranty			
Service and Warranty Service Plan	6 Services / 60,000km	6 Services / 60,000km	
Service and Warranty Service Plan Service Interval	6 Services / 60,000km 12 months / 10,000km	6 Services / 60,000km 12 months / 10,000km	
Service and Warranty Service Plan Service Interval Warranty	6 Services / 60,000km 12 months / 10,000km	6 Services / 60,000km 12 months / 10,000km	
Service and Warranty Service Plan Service Interval Warranty  Dimensions and Capacities	6 Services / 60,000km 12 months / 10,000km 3 years / 100,000km	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)  Gross Combination Mass (GCM)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6725	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6940	
Service and Warranty  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)  Gross Combination Mass (GCM)  Ground Clearance (mm)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6725  180	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6940  180	
Service and Warranty  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)  Gross Combination Mass (GCM)  Ground Clearance (mm)  Gross Vehicle Mass (GVM)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6725  180  5325	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6940  180  5540	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)  Gross Combination Mass (GCM)  Ground Clearance (mm)  Gross Vehicle Mass (GVM)  Height (mm)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6725  180  5325  2635	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6940  180  5540  2635	
Service and Warranty  Service Plan  Service Interval  Warranty  Dimensions and Capacities  Front Overhang (mm)  Front Tread (mm)  Fuel Tank Size (L)  Gross Combination Mass (GCM)  Ground Clearance (mm)  Gross Vehicle Mass (GVM)  Height (mm)  Length (mm)	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6725  180  5325  2635  6990	6 Services / 60,000km  12 months / 10,000km  3 years / 100,000km  1150  1690  95  6940  180  5540  2635  6990	



Dimensions and Capacities		
Turning circle (tyres, m)	6.5	6.5
Wheelbase (mm)	3935	3935
Width (mm)	2080	2080
Top Speed (km/h)	100	100



## **LINE DRAWING**



### **EXTERIOR COLOURS**

FOR ILLUSTRATIVE PURPOSES ONLY.

#### **MONOTONE**



058 - Ivory White



#### Disclaimer:

The information contained within or made available on any Toyota platform or note including but not limited to, this website/brochure/specification sheet, is provided for information purposes only. While we make reasonable efforts to update the information on our platform/s, Toyota Motor Corporation of Japan, and Toyota South Africa Motors (Pty) Ltd makes no representations, warranties, or guarantees, whether express or implied, that the content is accurate, complete or up to date, and all information contained herein is subject to change without notice.

Vehicle specifications may vary depending on the model, trim level, and market. Colours depicted on print and web material may not match the actual vehicle colour. Fuel consumption figures are estimates based on standardised testing conditions and actual results may vary due to (but not limited to) driving style, vehicle loading, tyres, wind, traffic, and accessories. All dimensions, capacities, and performance figures are approximate. Some features/options may be optional or only available on certain models/trim levels. Images and illustrations are for illustrative purposes only and may not reflect the actual vehicle.

Your use of, or reliance on, any information or contents herein is entirely at your own risk. Toyota Motor Corporation of Japan and Toyota South Africa Motors (Pty) Ltd (including its owners, agents, consultants, employees, and any affiliated person(s) are not responsible for any loss or damages related to your use of, reliance on, or understanding of any information or contents on this or any other Toyota platform. This includes, without limitation, any direct, indirect, special, incidental, consequential, or punitive damages in terms of any contract, delict (breach of a duty of care) or law.

Furthermore, Toyota Motor Corporation of Japan and Toyota South Africa Motors (Pty) Ltd do not guarantee the uninterrupted or error-free operation of any platform or the availability of content, and are not liable for any interruptions, errors, or damages caused by any technical issues or limitations of these platforms, including but not limited to, server downtime, software malfunctions, or internet connectivity issues.







